


Dining Chair CF500620



PART LIST


А	В	С	D
Back 1 PC	Seat 1 PC	Stretcher 1 PC	Front Leg 2 PCS

HARDWARE LIST

#1	#2	#3	#4
1/4"x5/8"L	φ10.5xφ7.0x1.5	φ16xφ7.0x1.5	M4
Bolt 10 PCS (Extra 1)	Spring Washer 10 PCS (Extra 1)	Flat Washer 10 PCS (Extra 1)	Allen Wrench 1 PC


Step 1. Lay back (part A) down on a soft flat surface, such as carpet. Attach seat (part B) to back (part A) using bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2. Attach stretcher (part C) to back (part A) using bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 3. Attach front legs (part D) to seat (part B) and stretcher (part C) using bolts (part #1), spring washers (part #2), flat washers (part #3) and allen wrench (part #4).

NOTE: Please fully tighten all bolts at this time.



Step 4. Carefully turn unit upright. Repeat steps 1-3 to assemble remaining chair.

