

VIGO

Pull-Down Spray Kitchen Faucet Model VG02027

MODEL VG02027

FEATURES

- · Solid brass construction
- · Spiral pull-down spray head
- · Spray face that resist mineral build up
- · Finish resist corrosion and tarnishing
- · Ceramic disk cartridge · Single hole construction
- · 360° Swivel
- · Single lever sprayer


PACKING LIST

- · Faucet Assembly
- · Sprayer
- · Allen Key
- · Two Metal braided hoses
- · Plastic Holder
- · Hex Bit





DΙ	M	IFI	N	S	\cap	N	S
υı	IV		N	O	ıv	I۷	U

MODEL#	HOLE	FAUCET	SPRAYER
	DIAMETER	HEIGHT	REACH
VG02027	1 3/8"	23 1/2"	9 3/8"



NOTE: All faucets are compliant to CEC 2016 regulations.





ALLEN KEY (REMOVES HANDLE TO ACCESS CARTRIDGE)

PACKAGE CONTENTS RUBBER RING PLATE METAL RING PLASTIC HOLDER

SPRAYER

REQUIRED TOOLS

PIN

Adjustable wrench Allen key - supplied (to remove cartridge if needed) Plumber's putty - optional Plumber's tape Flat screwdrivers

TWO METAI

SAFETY TIPS

If you use soldering for the installation of the faucet, the seats, cartridges and washers will have to be removed before using flame. Damage caused by improper soldering will void the warranty.

Protect your eyes with safety glasses when cutting or soldering water supply lines.

IMPORTANT POINTS

Prior to beginning installation, turn off the cold and hot water lines and open the hot and cold knobs on the old faucet to release pressure.

When installing your new faucet, turn the connector nuts finger-tight, then use one wrench to anchor the fitting and a second wrench to tighten the nut. Connections that are too tight will reduce the integrity of the system and potentially cause product failure which could lead to water damage. Wrap all threaded connections with plumber's tape available at your local hardware or plumbing supply store. Always wrap in a clockwise direction. Not all necessary supplies to install your faucet are included, however, they are available wherever plumbing supplies are sold.

Prior to installing the faucet please FLUSH THE HOT AND COLD WATER SUPPLY LINES that are or will be connected to the new faucet to remove scale, solder or their impurities which could damage the faucet and potentially void the warranty.

MAINTENANCE


Your new faucet is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will scratch, dull, and/or damage the finish and void the warranty.

INSTALLATION

Installation must be done by a qualified licensed plumber.

Prior to installation please read the instructions thoroughly, confirm that all parts are included and visually inspect the unit for any defects.

If you have any questions please contact the Vigo Technical Support Department before proceeding with installation.



::kitchensource.com

PI ATF

5. (IF NOT DONE ALREADY) ATTACH SPRAYER TO FEMALE CONNECTION OF SPRAYER HOSE BY HAND AND TIGHTEN UNTIL SECURE. MAKE SURE THE BLACK WASHER WITH SCREEN IS SFATED AND INSTALLED PROPERLY

ORDER AS DEPICTED IN DIAGRAM TO PREVENT

DAMAGE TO FAUCET AND SUPPLY LINES.

4. PLACE THE FAUCET ON TOP AND

SECURE WITH THE SET SCREW.

USE WASHER WITH SCREEN AT CONNECTION POINT BETWEEN SPRAYER AND SPRAYER HOSE. THIS
WILL STOP DEBRIS FROM TRAVELING INTO THE SPRAYER HEAD AND EFFECTING ITS
FUNCTIONALITY. PLEASE NOTE THAT THE SCREEN WASHER WILL NEED TO BE REMOVED AND
CLEANED APPROXIMATELY ONCE EVERY 3 MONTHS TO AVOID BUILD JUE AND LOW WATER FLOW

COUNTERTOR

PLATE

6. ATTACH THE FEMALE CONNECTIONS OF THE FLEXIBLE HOSES TO THE COLD AND HOT WATER SUPPLY.

ENSURE THAT YOU USE PLUMBER'S TAPE AND ADJUSTABLE WRENCH,
DO NOT OVER TIGHTEN AS THIS COULD CAUSE PRODUCT FAILURE
LEADING TO WATER DAMAGE.



SET SCREW

7. AFTER INSTALLATION IS COMPLETE, TURN ON THE WATER SUPPLY AND ALLOW BOTH HOT AND COLD WATER TO RUN SEPARATELY FOR AT LEAST TWO MINUTE EACH. WHILE WATER IS RUNNING, CHECK FOR LEAKS. IT IS IMPORTANT TO VIEW THE CONNECTIONS AT THE MALE AND FEMALE FLEXIBLE HOSE CONNECTIONS. IF LEAKS ARE DETECTED, REFER BACK TO THE INSTRUCTIONS AND ADJUST ACCORDINGLY. TIGHTENING NUTS SLIGHTLY MAY STOP ANY MINOR LEAKS.

6



TROUBLESHOOTING

PROBLEM	POTENTIAL CAUSE	CORRECTIVE ACTION	
1 - Leaks from handle	1.A - Cartridge unseated 1.B - Cartridge defective	1.A - Remove cartridge from housing, wash thoroughly with hot	
2 - Insufficient flow rate 3 - Leak at connection points	2.A - Dirty aerator	water and reseat in housing. 1.B - Contact Vigo Technical Support for replacement.	
4 - Loose faucet body	2.B - Clog in supply hose / line	2.A - Remove and soak / clean with a non abrasive agent (i.e.	
5 - Sprayer button stops working	3.A - Sprayer hose not tight 3.B - Flexible hose leaking at body or connection point	vinegar). 2.B - Remove sprayer or supply line and flush lines	
	4 Metal nut became loose	3.A - Remove sprayer and check integrity of the black washer. Make sure the washer is seated properly and retighten. 3.B - Tighten hoses. If this does not resolve the issue, remove the flexible hose and rethread, checking to make sure the connection is secure. Make sure to use pipe tape.	
	5.A - Debris in aerator 5.B - Wear and tear on button		
		4 From under the counter, use an adjustable wrench and tighten the metal nut to the hollow pipe. Make sure the faucet is perpendicular to the counter.	
		5.A - Remove and clean aerator. 5.B - Contact Vigo Technical Support for replacement.	

PARTS LIST - For any parts needed but not shown, please contact Vigo Technical Support

	PART#	FINISH	SUPPLY DATE INDICATOR (INTERNAL USE ONLY)
Sprayer Hose	74044	CH, ST, MB	P
Sprayer	78099	CH, ST, MB	P
Handle	78097	CH, ST, MB	P
Stem Assembly	78098	-	P
Magnet Sleeve	78100	-	P
Sedal Cartridge	74035	-	P
Metal braided Hose	74020	-	P
Sprayer Washer	74008	-	P
lack Washer with Screen	74010	-	P
Quick Connect Assembly	78101	-	P





