


# \*Use this side for

# **5149 Series Waste Container**



Front edge of paper to back of door.



### \*Use this side for Single 35 & 50 Qt. & Double 27 Qt.

## **5149 Series Waste Container** Installation Template



**ESTIMATED ASSEMBLY** TIME:

**20 MIN** 

**CARE AND MAINTENANCE:** 

**CLEAN WITH A DAMP CLOTH** AND WIPE PARTS DRY

PARTS LIST: PULLOUT CHASSIS WASTE CONTAINER CHASSIS WASTE CONTAINER(S) (8) #6 X 1/2" FLAT HEAD SCREWS (5) #8 X 3/4" PAN HEAD SCREW DOUBLE SIDED TAPE



- Use the #8 x ¾" Phillips head screws provided to secure the unit to the floor. The slide system can be separated if necessary to aid in installation, but removal is not required. (See FIG 1
- Ensure that the door mounting brackets allow the mounting screws to engage a part of the door that is at least 3/4" thick. (On a 5-panel door, this would be the outer side pieces, or styles) Inset doors would move the brackets toward the center of the unit while full overlay doors would require the brackets to move outward. (See FIG 3) Use the double sided tape provided to temporarily attach the door to the mounting brackets.
- Carefully open the unit, being sure not to disengage the double sided tape. Once the unit is open, use the #6 x ½" flat head screws to permanently attach the door to the unit. All (8) screws must be used for proper function. Space screws at opposing corners as much as possible.

Vertical mounting slots have been used in the bracket that attaches directly to the door. Use these slots for vertical adjustment. (See FIG 4)

Horizontal adjustment is achieved by loosening all 4 of the 3/8" nuts that connect the two brackets and moving the door left to right as needed. (See FIG 4)

For door tilt adjustment, loosen the 4 #3 phillips head screws below the skirt and adjust. The rear screws are slotted to allow the door to pivot at the front of the bracket. (See FIG 5) Keeping the front screws 'snug' will aid in adjustment.

