

**APPLICATIONS:** Bracket kit converts 2132C slides to fit face frame applications. No tools are needed; front and rear brackets snap onto slides. Rear bracket has a 2" (50.8) adjustment range. **This product is covered by U.S. (#5,904,412) and various foreign patents issued and/or pending.** 

Part Number 4180-0321-XE For Use With Model 2132C

See Model 2132C technical sheet for additional slide details.

#### **Attach Brackets to Slide Member**

First, separate slide members by actuating the disconnect lever. Brackets are attached to cabinet (large) member.

## **Attach Front Bracket**

- Position bracket on slide so tab engages second hole on slide. Bracket flanges will face inboard. See Figure 1.
- 2. Rotate bracket until it snaps in place, flush with front.

## **Attach Rear Bracket**

Push rear bracket onto the slide. Ensure locking lug on plastic slider engages
the mating hole in the slide member and the bumper on the slide seats into the
plastic slider on the bracket. See Figure 1.

#### **Mount Slide to Cabinet**

- Secure a .75" x 2" vertical mounting strip to the rear wall or cabinet back for each slide.
- Position the front bracket on the face frame opening and move it forward until the self-register stop hits the inside of the face frame opening. Install screw in the slotted mounting hole. Do not tighten screws completely at this time.
- 3. Extend the rear bracket until it contacts the rear vertical mounting strip. \*NOTE: Maximum adjustment range is 2" from the back of the cabinet to the rear of the slide. Check that both cabinet members are vertically and horizontally parallel. Mount the rear bracket using the two vertical slots. Make any necessary adjustment. See Figure 2.
- Secure the rear bracket with a screw in the round hole. Secure the front bracket with a screw in the round hole and tighten the original screw. See Figure 2.

### **Mount Slide to Drawer**

- 1. Install drawer member through vertical slots.
- Insert drawer member making sure ball bearing retainers are fully forward. Close drawer completely.
- Adjust vertical position and install two more screws in round holes after free movement is achieved. See Figure 3.

# Slide Ordering Information

Bracket can be ordered as a kit or in bulk. Mounting screws are not included.

Each kit contains enough brackets to mount one pair of slides. Order kit part number 4180-0321-XE. Bracket kit includes:

2 each front bracket Part number 4010-0519-CE 2 each rear bracket Part number 4080-0221-CE 1 each installation sheet

Total Kits Required

Kit Part Number

For Bulk, order 2 front and 2 rear brackets per pair of slides.


20 Each 4010-0519-CE 20 Each 4080-0221-CE


Total Brackets Required Bracket Part Numbers


RoHs compliant.


Note: Specifications, materials, prices, terms, and delivery are subject to change without notice.

For the most current technical information visit www.accuride.com











## ACCURIDE INTERNATIONAL INC.

12311 Shoemaker Avenue Santa Fe Springs, CA 90670

TEL (562) 903-0200 FAX (562) 903-0208 www.accuride.com

Manufacturing, Engineering, and Sales

United States • Germany • Japan • Mexico • United Kingdom • China Copyright © 2012 Accuride International Inc. 3700-9395(1063)-MK095-R8-1112