



Chrome Wire Shoe Rail

1. The shelf requires 3 holes to be drilled. Hole diameter is $\frac{1}{4}$ " x $\frac{1}{2}$ " deep. Use the shoe rail as a template to mark exact hole placement.
2. Insert Wire Shoe Rail into shelf. See Figure 2.