


- Using the marks made in Step 1, attach the cabinet member of the slide to the closet partition. If using system holes, use the Euro Screws provided in the hardware bag, otherwise use #8 x 1/2" screws. (See Figure 1)
- Insert the pants and/or tie rack into slides, take care to align the slides on both sides at the same time.

## **Wood Pants and Tie Rack**

The wood pants and tie racks are designed to mount to the partitions in a closet system. They are 24" and 30" wide.

- Determine and mark the mounting height of the rack. Making sure to arrive at least 6 1/2" BELOW the next highest shelf. The slide should be recessed slightly (~1/6") from the face of the partition.
- Remove both slides from the product by pressing the release lever on the product member, and pulling away from the wood rack.



 Push the product completely closed, and then pull out completely to check operation. Installation is now complete. (See Figure 2)

an **Eefa**CO. Store