

Omega National

P R O D U C T S

Super Susan Installation

Installation Instructions

Step 1: Make sure the Detent in the steel bearing is engaged.



Step 2: Place the SSusan in the cabinet in the desired location



Step 3: Turn the SSusan to expose the corner of the base plate, making sure to apply enough downward pressure to disengage the detent while not allowing the base plate to turn.



Step 4: Screw the SSusan down to the shelf (pre-drilling may be necessary) through the corner of the base plate. Repeat for the other 3 Corners.

