



“Reflections for a new millennium”

Installation Instructions for:

**Double Door, Triple Door, Four Door
Signature/ Vanderbilt Cabinets**

Dear AFINA Customer:

We appreciate your purchase of our **AFINA** Bath Cabinet, and would like to provide you with the following helpful hints.

- For protection in shipping, the **GLASS SHELVES** for your cabinet have been neatly placed under the cabinet body (top or bottom). They are clearly identified by a label marked “**GLASS SHELVES**”. Please look carefully and remove **before** installation.
- **SHELF PINS** are inside the cabinet in an envelope marked “**SHELF PINS**”. Remove before installation.
- It is important to make sure the cabinet body is level and plumb upon installation. Use a leveling instrument to ensure accuracy, or the door may not close and/or secure itself properly.
- When **RECESSING** the cabinet, use the two pre-drilled holes on each side of the cabinet interior (top and bottom). Screws are not supplied as we do not know the type of material you are going into. Four (4) screws are needed. Make sure the cabinet is level and plumb before securing into framing studs.
- When **SURFACE MOUNTING** – See separate “**OPTIONAL**” **SURFACE MOUNTING INSTRUCTIONS** with your optional surface mount kit.
- When cleaning your new Afina cabinet, we recommend a mild cleanser, applied first to a rag or paper towel. Do not spray directly on to the mirror or frame.

We are confident your **AFINA** cabinet will reflect the quality and prestige you wish to convey in your home or business environment.

Thank you for purchasing **AFINA** products.