

MOUNTING AND WIRING INSTRUCTIONS FOR POTRACK FIXTURES

CAUTION:

- 1. THIS FIXTURE HAS THE POTENTIAL OF WEIGHING MORE THAN 50 LBS. THEREFORE IT MUST BE INSTALLED INDEPENDENT OF THE OUTLET BOX.**
- 2. TURN OFF ELECTRICITY AT THE MAIN FUSE BOX BEFORE INSTALLATION.**
- 3. RISK OF FIRE: DO NOT LAMP FIXTURE GREATER THAN WATTAGE SHOWN ON MAXIMUM WATTAGE LABELS WHERE ATTACHED.**

STEP 1: THIS FIXTURE MAY HAVE OTHER INSTRUCTION SHEETS, REFER TO THEM FOR THE COMPLETE ASSEMBLY OF THIS FIXTURE.

STEP 2: TO MOUNT INDEPENDENT OF THE OUTLET BOX THE OUTLET BOX MUST BE SECURED TO A BRACE ABOVE THE OUTLET BOX.

STEP 3: FASTEN THE CAST HICKEY THROUGH THE OUTLET BOX AND INTO THE BRACE WITH (4) #8 X 1-1/2 LONG SCREWS AS SHOWN IN fig a. PREDRILL HOLES INTO BRACE WITH A 1/8" DIA. DRILL BIT. THE OUTLET BOX IS SHOWN CUTAWAY AND THE CEILING DRYWALL IS REMOVED TO SHOW THE HICKEY BEING INSTALLED.

STEP 4: THREAD THE NIPPLE INTO THE HICKEY SO IT IS BELOW THE CEILING LEVEL 1-1/2". SECURE NIPPLE WITH LOCKWASHER AND HEX NUT AS SHOWN IN fig b.

STEP 5: DETERMINE THE LENGTH OF CHAIN YOU NEED FOR YOUR FIXTURE HEIGHT AND REMOVE OR ADD LINKS. THREAD FIXTURE WIRE/GROUND WIRE THROUGH THE CHAIN LINKS AND THROUGH THE LOOP(S) ON THE CANOPY.

STEP 6: SPLICE THE RIBBED SIDE OF THE PARRALLEL WIRE TO THE WHITE SUPPLY WIRE FROM THE OUTLET BOX WITH WIRE CONNECTOR (NOT SUPPLIED). SPLICE THE SMOOTH SIDE OF THE PARRALLEL WIRE TO THE BLACK SUPPLY WIRE FROM THE OUTLET BOX WITH WIRE CONNECTOR. SPLICE GROUND WIRES WITH WIRE CONNECTOR.

STEP 7: PUSH ALL WIRES INTO OUTLET BOX AND RAISE CANOPY OVER NIPPLE AND SECURE TIGHTLY WITH CAP NUT. ADD LAMPS AND OTHER ACCESSORIES. TURN ON ELECTRICITY.

