

ROLLING SHELVES

INSTRUCTIONS FOR INSTALLING OPTIONAL ACCESSORIES MOUNT TO SHELF BRACKETS

STANDARD MOUNTING ¾ EXTENSION SLIDES (WHITE)

- 1) ATTACH THE INCLUDED SCREWS THROUGH THE GUIDES AND INTO THE LOWER SET OF HOLES ON THE “L” BRACKET. (SEE PICTURE).
- 2) ATTACH THE “L” BRACKETS TO THE BASE OF YOUR CABINET OR ANY OTHER MOUNTABLE SURFACE BY USING THE SUPPLIED 5/8” SCREWS THROUGH THE BOTTOM OF THE “L” BRACKET AND INTO THE MOUNTABLE SURFACE (SEE PICTURES). USE AT LEAST 2 SCREWS PER BRACKET.

TIP: USE THE SHELF AS A GUIDE TO MOUNT THE BRACKETS BY INSERTING THE GUIDES INTO EACH OTHER AND PLACING THE SHELF WHERE YOU WANT IT. THEN SIMPLY SCREW THE BRACKETS DOWN TO THE MOUNTABLE SURFACE.



MOUNT TO SHELF BRACKETS FOR *FULL EXTENSION* GUIDES

- 1) TAKE EACH GUIDE AND EXTEND TO FULL LENGTH. PUSH DOWN ON PLASTIC HOLDER CLIP WHICH IS IN THE CENTER OF THE GUIDES. THIS WILL ALLOW THE GUIDE TO BECOME 2 PIECES. THE PART WITH THE BALL BEARINGS WILL ATTACH TO THE “L” BRACKETS AND THE OTHER PART (NON-SLIDING) WILL ATTACH TO THE SHELF.
- 2) ATTACH 4 OF THE INCLUDED SCREWS THROUGH THE GUIDES AND INTO THE LOWER SET OF HOLES ON THE “L” BRACKET. YOU WILL ONLY USE 1 SCREW PER BRACKET. ATTACH THE NON-SLIDING PART OF THE GUIDE TO THE SHELF BY MAKING A MARK 7/8” UP FROM THE BOTTOM OF THE SHELF (WITH THE ½” BOTTOM ALREADY ATTACHED) AND RUNNING THE FULL DEPTH OF THE SHELF. THIS LINE IS THE CENTER LINE FOR THE GUIDE. FLUSH THE FRONT OF THE GUIDE (BENT END) WITH THE FRONT OF THE SHELF. SCREW THE ½” SCREWS THROUGH THE GUIDES AND INTO THE SIDES OF THE SHELF, ALIGNING THE CENTER OF THE HOLES WITH THE LINE YOU MARKED.
- 3) ATTACH THE “L” BRACKETS TO THE BASE OF YOUR CABINET OR ANY OTHER MOUNTABLE SURFACE BY USING THE SUPPLIED 5/8” SCREWS THROUGH THE BOTTOM OF THE “L” BRACKET AND INTO THE MOUNTABLE SURFACE. USE AT LEAST 2 SCREWS PER BRACKET.

FULL EXTENSION GUIDE INSTALLATION INSTRUCTIONS ON REVERSE SIDE.

FULL EXTENSION GUIDE INSTALLATION INSTRUCTIONS (OPTIONAL)

- 1) EXTEND EACH GUIDE TO IT'S FULL LENGTH. PUSH DOWN ON THE BLACK PLASTIC TAB LOCATED IN THE CENTER OF THE GUIDE. WHILE PUSHING DOWN ON THE TAB, PULL THE TWO GUIDE SECTIONS APART. (SEE PHOTO)



- 2) THE SECTION THAT HAS THE ROWS OF BALL BEARING WILL BE THE PART THAT IS ATTACHED TO YOUR CABINET



- 3) LOCATE THE POSITIONS IN YOU CABINET TO INSTALL YOUR GUIDES, MAKING NOT OF WHICH GOES ON THE RIGHT OR LEFT.
- 4) WHEN FASTENING THE GUIDES, CHECK THAT THEY ARE **LEVEL** AND **PARALLEL** TO EACH OTHER.
- 5) USE A MINIMUM OF TWO SCREWS TO ATTACH EACH GUIDE TO YOUR CABINET, THROUGH THE HOLES ON THE GUIDES.
- 6) ONCE YOUR GUIDES ARE ATTACHED TO YOUR CABINET, YOU CAN INSTALL YOUR SHELF.
- 7) **CAREFULLY** SLIDE THE SHELF GUIDES **STRAIGHT INTO** THE SECTION THAT YOU ATTACHED TO THE CABINET. SLIDE THE SHELF BACK AND FORTH SEVERAL TIMES TO SEAT THE GUIDES.
- 8) THEY SHOULD MOVE EASILY BOTH FORWARD AND BACK. IF NOT; CHECK TO MAKE SURE THAT THE CABINET MOUNTED GUIDES ARE LEVEL, PLUMB AND HAVE THE CORRECT SPACING. IF NOT, CORRECT AND RE INSTALL THE SHELF.