



Installation Requirements

Our 3 Tier Hanging Shelf is not only a durable storage solution but an accent piece to compliment any home decor. With natural teak shelves and matte black brackets, the teak hanging shelf combines organic beauty with modern lines.

Teak wood, prized for its weatherproof durability, has been favored by shipbuilders for centuries. In addition, its high concentration of natural oils and tight wood grain makes it suitable for use in humid environments, including the kitchen and bathroom.

This installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every installation. View this document as a help sheet that provides considerations about general installation.

3 Tier Hanging Shelf System (FB-06660)

1. Locate 2 studs for your installation. Both brackets must be installed into studs no more than 36 inches apart.
2. Drill a pilot hole & fasten the first bracket to your wall starting with the top fastener. It helps to use a drill bit that is slightly smaller than the fastener when drilling the pilot hole.



3. Using a level, align your bracket and proceed with drilling additional pilot holes and fastening.
4. Repeat steps 1-3 for the second bracket and ensure you are level across both brackets to ensure that your shelves will not slant.
5. Once the bracket system is in place, insert your desired shelf planks.

Final Steps

Enjoy your work. We are happy that you chose to support your project with Federal Brace brackets. We would be very grateful for images of your finished installation. Everyone enjoys seeing Federal Brace supports at work. Also, know that the highest compliment Federal Brace can receive is a reference from our customers to their friends and family. If you have enjoyed your buying experience with Federal Brace, please let someone know. Thank you!