



Installation Requirements

This Maple Live Edge Floating Shelf arrives unfinished, giving you the flexibility to accent the other elements of your design exactly the way you want. The warm, natural tones of the maple wood will work beautifully with modern, cool tones in your home or commercial space. All of our maple live edge slabs are kiln-dried, finely sanded, and the bark is removed to provide a smoother surface that requires less intensive care.

This installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every installation. View this document as a help sheet that provides considerations about general installation.

Before beginning you will need the following components:

- 2- Floating Shelf Rods
- 4 - 2.5" Hex Lag Screws

Maple Live Edge Floating Shelf (39932, 39933)

1. Locate the live edge shelf, 2 floating shelf rods, 4 lag screws.
2. Locate two studs spacing 16" on center and mark them before you install.
3. Hold the rod in place and mark your holes. Repeat for consecutive rods.
4. Use a drill bit slightly smaller than the holes (0.25") and drill pilot holes. Once the pilot holes are drilled, put the rod in place and install fasteners.



5. Prior to tightening fasteners completely, check level across the rods. Adjust as needed and make final tightening of fasteners.

6. Install the shelf by sliding through the predrilled holes on shelves for the rods to fit.

Final Steps

Enjoy your work. We are happy that you chose to support your project with Federal Brace brackets. We would be very grateful for images of your finished installation. Everyone enjoys seeing Federal Brace supports at work. Also, know that the highest compliment Federal Brace can receive is a reference from our customers to their friends and family. If you have enjoyed your buying experience with Federal Brace, please let someone know. Thank you!