

homestyles®

20 05525 0691


# Pantry

## IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.


Do not use power tools above 8 volts to assemble.




## Part List



A.  
Door  
2 pcs.




B.  
Door  
2 pcs.




C.  
Side Panel  
1 pc.



D.  
Side Panel  
1 pc.



E.  
Side Panel  
1 pc.



F.  
Side Panel  
1 pc.

For assembly see instructions in carton 20 05525 0692.