

homestyles®

20 05530 0541

Bunk Bed




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List



A.
Lower End Panel
2 pcs.

For assembly see instructions in carton 20 05530 0543.