



Installation manual





art. 520




 x 11 **6** **10**

 x 2 **11**



 x 2 **21**










x 1





x 1





	 x N	 x N	 x N	 x N	 x N
521	2	4	5	3	6
523	2	4	5	4	8
524	2	4	5	4	8
525	3	6	7	5	10
526	4	8	9	5	10
527	4	8	9	6	12







6



7



8



9