


INSTALLATION INSTRUCTIONS CHARCOAL FILTER

MODELS:

01A / 02A / 03A / 04 / 011 / 021 / 06 and 07

Contents:

- #1 Filter Clips – Use four per filter
- #2 Charcoal filter pads – Use one per filter



Installation Instructions:

1. Snap the four filter clips (#2 above) over the sides of the wire-mesh filter in photo above. The long side of the clip goes on the topside (the charcoal side) of the wire mesh filter.
2. Place the charcoal filter on the topside of the wire mesh filter. Slip sides of charcoal filter under the long end of the filter clips.
3. Insert the assembled wire-mesh and charcoal filter into the blower.
4. Replace charcoal filters as needed. For best service, replace every 4 – 6 months.

VMI Inc has a policy of continuous improvement and reserves the right to modify (at any time without notice) any of its products designs, components and specifications. For exact dimensions, see the Installation Instructions included with the product.