




FORMOSA

INSTALLATION GUIDE

FVN3136ACA-FC

CONTENTS:

Mirror	FMR3132ACA	PAGE 2
Cabinet	FCB3136ACA	PAGE 3
Sink	FCT2036WH-CMB	PAGE 3




FVN3136ACA-FC FORMOSA INSTALLATION GUIDE


●●●kitchensource.com
1.800.667.8721




FVN3136ACA-FC
Vanity Front




FCT2036WH-CMB
Countertop Front




FMR3132ACA
Mirror Front




FCB3137ACA
Bottom Cabinet Front




FCB3136ACA
Cabinet Front




FCB3137ACA
Bottom Cabinet Back



FCB3136ACA
Cabinet Back



NOTE: All dimensions & specifications are approximate and subject to change without notice.




FVN3136ACA-FC FORMOSA INSTALLATION GUIDE

●●kitchensource.com
1.800.667.8721




TOOLS FOR ASSEMBLY




MIRROR INSTALLATION

- 1** Measure distance between the holes and mark it on the wall using a level.





- 2** Press the anchors into the holes.



IMPORTANT: Consult an expert for the proper screws/bolts to use when attaching to various constructions. Screws provided do not attach to all wall construction types. Anchors are not required if brackets are installed in stud.

- 3** Hang mirror on the screws.







CABINET AND SINK INSTALLATION

- 1** Connect cabinet (A) to cabinet (B) with iron sheet.


IMPORTANT: Consult an expert for the proper screws/bolts to use when attaching to various constructions. Screws provided do not attach to all wall construction types. Anchors are not required if brackets are installed in stud.




- 2** Mark anchor mounting hole locations on wall as shown. Drill holes in the finished wall as required. Then insert the anchor(1) into the holes and secure the wall bracket(2) with the screws(3).




- 3** Install sink.



- 4** Apply a bead of silicone on the top of the cabinet (C) and place sink (D) on the cabinet.









FVN3136ACA-FC FORMOSA INSTALLATION GUIDE

●●kitchensource.com
1.800.667.8721







DRAWER REMOVAL & INSTALLATION

REMOVAL




INSTALLATION



FVN3136ACA-FC | FORMOSA | INSTALLATION GUIDE


PAGE 4



P-TRAP AND POP-UP INSTALLATION INSTRUCTIONS


NOTE:

Your item may appear slightly different from the illustration.




POP-UP INSTALLATION INSTRUCTIONS


FOR SINKS WITHOUT OVERFLOW



OR


FOR SINKS WITH OVERFLOW





P-TRAP INSTALLATION

1 Install tail pipe (G)



2 Install p-trap (J)

