Imperial

Read Before Starting Installation!

Inspect your range hood prior to installing!

Any cosmetic defects must be reported to us prior to installation.

Once this hood is installed, ICP will NOT accept any responsibility

for any cosmetic blemishes, scratches or dents in the Canopy.

Save all original packaging if you wish to return for any reason!

FIRST:

Check your local building and electrical codes.

WARNING:

To reduce the risk of fire or electrical shock, Do Not use any two speed motor units with a Solid State control devise.

CAUTION:

To reduce the risk of fire or personal injury and to properly exhaust air, be sure to duct air to the outside. DO NOT vent exhaust air into spaces within wall, attics, ceilings, crawl spaces or garages. When venting to the outside make duct run as short and straight as possible. Avoid using elbows if at all possible. DO NOT use duct pipe smaller than the outlet duct opening on the hood, this will reduce performance and void the warranty. DO NOT use flex ducting. Also, use either a Roof Cap or Wall Cap to end run. Be sure that all joints are taped securely in place.

It is essential to have the proper distance between the bottom of the range hood and the cooking surface below. In most cases the cooking appliance manufacturers specifications will establish the fire safe minimum distance required, although there are other factors to consider:

- Local Building Codes
- Cross directional air movements ie: open windows, air conditioning/heating outlets, cooling fans, etc.
- Overall size of the cooking appliance and surrounding countertop surfaces.
- Range hood model selected.

Minimum distance between cooking surface and the bottom of the hood is 30" and 36" is the maximum distance. Keep in mind, increasing the distance will decrease the performance.

Flush Mount Installation Details:

MODELS:

MODELS:


G3000SD2, G3000SD4, G3000PS1 3000SD2, 3000SD4, 3000PS1


CABINET: Be sure cabinet bottom is level, side to side and front to rear.

- For the "SD" units prepare cabinet by cutting an 8" x 8" hole in bottom, 3/4" from wall and on Center line.
- For the "PS1" units prepare the cabinet by cutting a 10 3/8" (D) x 20 1/4" (W) hole in the bottom, 1/2" from wall and center line.
- Shelves and top to be cut to clear 7" round pipe. Also, cut holes for electrical wires.

NOTE: Bolts, washers and nuts supplied. Remove the Drawer before positioning the hood under the cabinet. *See next page on how to remove.

- Position hood against cabinet bottom and against wall. Mark the underside of cabinet through each key-hole for location of each bolt hole.
- Drill 3/16" holes through cabinet bottom. Insert bolts with small washer under head of bolt through cabinet bottom from inside the cabinet.
- Again, position hood under cabinet with bolts through key-holes. Starting with front key-holes, place large washer on bolt, attach the wing-nut to bolt, secure both front wing-nuts. Push hood back against wall, secure large washer and the wing-nuts on rear bolts.
- Re-install the pull out drawer.
- Connect duct and tape all joints.
- Replace Filters





ELECTRICAL:

- Stub enough wire into cabinet to reach in front of vent pipe.
- Enter the cabinet 3 1/4" left of center for (SD unit) or 2 1/4" for the (PS1 unit).
- Remove splice box cover before mounting the hood.
- After hood is mounted attach house wires to leads in hood.
- Secure locknut to conduit and check wiring for compliance with all local codes.
- Replace splice box cover.

Flush Mount Installation Details:

MODELS:

MODELS:


G3000SD2, G3000SD4, G3000PS1 3000SD2, 3000SD4, 3000PS1

TO REMOVE DRAWER FROM 3000

A) Pull out drawer until it stops; depress drawer top at the point indicated by arrow "A" while pulling the drawer outward.

WHEN THE DRAWER STOPS AGAIN...

B) Depress two black buttons indicated by arrows marked "B" while pulling the drawer outward. Drawer will come free of hood, HOLD SECURLY!




WOOD PANEL:

To determine the size of your front Wood Panel you must take two things into consideration:

- Actual size of the hood itself
- Design of surrounding cabinets

You want to hide the hood and to do so you need it to line up with the surrounding cabinets. We suggest you extend the Height and Width of the Wood Panel a bit beyond the actual size of the hood. So if you have a 36" hood your wood Panel might be 36.5" Wide by 6.5" High. The final choice on the size must be determined by your cabinet maker and yourself.



SERVICE:

::rangehoods.com

PARTS:

When calling in for Service we need the following information:

- Model Number (not serial number)
- Proof of Purchase
- Name of company you purchased the hood through.
- Name & Phone number of the person to contact to set up the service call.

Warranty on the Economy Hood is One Year Parts only. Warranty on all others is Five Years, Parts and Labor.

::rangehoods.com

Maintenance & Warranty Information

This product has the simplest of cleaning requirements.

All metal filters are dishwasher safe! Clean filters often for the best performance. How often depends on amount and type of cooking. When cleaning a painted hood, wash it with mild, soapy water ONLY! Wipe the hood thoroughly with clean

water and dry with soft cloth. When cleaning Stainless Steel use a cleaner specifically for Stainless Steel. Always rub with the grain using non-abrasive cleaning materials. Avoid

detergents, disinfectants or cleaning products in aerosol cans. NEVER use abrasive scouring powders on your hood! Some cleaning chemicals may damage the hood finish!

Exposed Center Panel Spot Lights: Incandescent 75 Watt Spot Lights (Par 20)

Recessed: Incandescent 75 Watt Bulbs

Exposed Front Panel Spot Lights: Halogen 50 Watt bulbs (R-20)

**Bulbs not included.

Warning: <u>Do not</u> use Halogen bulbs in sockets not intended for their use! They are to be used only in the Front Light Panels, not the Center Light Panels.

<u>Your Imperial Warranty:</u> Staple sales slip or cancelled check here. Proof of original purchase date is needed to obtain service under warranty.

Economy Units: One Year Limited Warranty on Parts Only.

Deluxe Units: Five Year Limited Warranty, Parts and Labor.

For five years from date of original purchase, we will provide parts and service labor in your home to repair or replace any part of the hood that fails due to a manufacturing defect. Call for service at (800) 851-4192

We do not cover service required due to improper installation or misuse of product. Please contact your dealer or installer. If we are called to the home, and the above is determined, there will be a service charge.

Warrantor is not responsible for incidental and consequential Damages.

SAFETY INSTRUCTIONS

Read and Save These Instructions

Warning: To reduce the risk of fire, electrical shock or injury to persons, observe the following:

A. Use this unit only in the manner intended by the manufacturer. If you have any questions, contact the manufacturer. Before servicing or cleaning unit, switch power off at service panel and lock Service Disconnecting Means to prevent power from being switched on accidentally. When the Service Disconnecting Means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.

Warning: To reduce the risk of a range top grease fire:

- A. Never leave surface units unattended at high settings. Boilovers cause smoking and greasy spillovers that may ignite. Heat oils slowly on low or medium settings.
- B. Always turn hood ON when cooking at high heat or when Flambéing foods (i.e. Crepes Suzette, Cherries Jubilee, Peppercorn Beef Flambé).
- C. Clean ventilating fans frequently. Grease should not be allowed to accumulate on fans or filters.
- D. Use proper pan size. Always use cookware appropriate for the size of the surface element.

Warning: To reduce the risk of injury to persons in the event of a range top grease fire, observe the following:

- A. SMOTHER FLAMES with a close-fitting lid, cookie sheet or metal tray, then turn off the burner. BE CAREFUL TO PREVENT BURNS. If flames do not go out immediately, EVACUATE AND CALL THE FIRE DEPARTMENT.
- B. NEVER PICK UP A FLAMING PAN you may be badly burned.
- C. DO NOT USE WATER, including wet dishcloths or towels, violent steam explosion will result.
- D. Use an extinguisher ONLY if:
- ⇒ You know you have a Class ABC extinguisher and you already Know how to use it.
- ⇒ The fire is small and contained in the area where it started.
- ⇒ The fire department is being called.
- ⇒ You can fight the fire with your back to an exit.

Warning: To reduce the risk of fire, electrical shock or injury to persons, observe the following:

- A. Installation work and electrical wiring must be done by a qualified person or persons in accordance with all applicable codes and standards, including fire-rated construction.
- B. Sufficient air is needed for proper combustion and exhausting of gases through the flue of fuel burning equipment to prevent back drafting. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American society for Heating, Refrigeration & Air conditioning Engineers (ASHRAE), and the local code authorities.
- C. When cutting or drilling into a wall or ceiling, do not damage electrical wiring and other hidden utilities.
- D. Ducted fans must always be vented to the outdoors.

Warning: To reduce risk of fire, use only Smooth Metal Ducting!