



CU-GRS + CU-GRR

INSTALLATION INSTRUCTIONS (Fasten through wall surface into a wood stud or heavy plywood backing.)

1. Use a stud finder to accurately locate the center of the stud.
2. Remove Cap on end of post to allow opening for mounting screw.
3. Place Grab Bar on wall at desired mounting location and mark screw hole location with pencil. Mark is made by inserting pencil through each post.
4. Drill 5/32" hole into the wall stud or wood backing.
5. Slip Backplates onto Grab Bar Posts.
6. Fasten the Grab Bar to mounting surface using #12 Pan Head Screw supplied and tighten.
7. Screw caps back into posts.

